

FAQ: CK-AMF9 / CK-AMF9ZK

Q: What is the difference between the CK-AMF9 and the CK-AMF9ZK?

A: The only difference between the units is the body color. The CK-AMF9 features a black body, while the CK-AMF9ZK features a Zombie green body

Q: What firearms will the CK-AMF9 fit on?

A: Compatible with Ruger LC9, Ruger LC9s, Ruger LC380, and Kel-Tec PF9.

Q: How do I install the CK-AMF9?

A: Easy to mount on the gun by simply pushing out and replacing the stock pins with the new screws (included).

Q: How do I sight in the laser?

A: There are two adjustment screws located on the laser. The elevation adjustment screw is on top of the laser; the for windage adjustment screw is on the right side of the laser.

Q: What size hex wrench do the adjustment screws use?

A: The adjustment screws use a .035 hex wrench. If you lose yours and cannot find one please contact Customer Service via email at info@laserlyte.com, and we will send you a new one.

Q: Does the CK-AMF9 have a pulse mode?

A: Yes, this laser does have a pulse mode. To program your laser to pulse, simply turn the laser on and with the laser on press and hold down the activation button until the laser begins to pulse (this may take up to seven seconds). Once the laser is pulsing let go of the activation button and the laser will turn off, when you turn the laser back on it will be in the pulse mode. To return to the constant on mode, simply repeat this process.

Q: Can this laser be mounted on the left hand side of my firearm?

A: Unfortunately the CK-AMF9 will not work on the left hand side of the firearm due to the way the firearm is manufactured.

Q: Does the CK-AMF9 cover the firearm's serial number? Is this legal?

A: The firearm's serial number is covered when you install the CK-AMF9. This is no different than any other rail mounted flashlight or laser accessory on a standard Glock or XD firearm. For clarification of potential state or local restrictions in your area please consult local authorities.

Q: What kind of batteries and how many does the CK-AMF9 use?

A: The CK-AMF9 uses four batteries, size 377.

Q: How long do the batteries last?

A: The battery life for normal usage is 5 hours in the constant on mode and 10 hours in the pulse mode.

Q: Where can I purchase replacement batteries for my CK-AMF9?

A: The 377 batteries are standard camera/watch/hearing aid batteries that can be purchased at your local Wal-Mart, Radio Shack, local drug store or any other place that sells watch or hearing aid batteries. You may also purchase 12 packs of replacement batteries directly from LaserLyte here:

<http://www.laserlyte.com/products/12-pack-of-377-batteries>

Q: What is the actual size of the CK-AMF9?

A: 4.22 (Length) x .58 (Width) x .38 (Height) inches.

Q: How much does the CK-AMF9 weigh?

A: This laser weighs .40 oz.