

FAQ: CM-15

Q: What firearms will the CM-15 fit on?

A: Compatible with all firearms with at least three inches Picatinny rail system.

Q: How do I install the CM-15?

A: The CM-15 laser is easily mounted on a three-inch or longer Picatinny rail and secured with two crossbar screws.

Q: How do I sight in the laser?

A: There are two adjustment screws located on the laser. The elevation adjustment screw is on top of the laser; the windage adjustment screw is on the right side of the laser.

Q: How do I turn the CM-15 on?

A: The CM-15 has two on/off options:

- The ON position turns it on.
- The MOM position for the remote pressure switch with a ten-inch length, two-inch tape switch area with copper braided cord, included.

Q: What kind of batteries and how many does the CM-15 use?

A: The CM-15 uses one battery, size CR123.

Q: How long do the batteries last?

A: The battery life for normal usage is six or more hours.

Q: Where can I purchase replacement batteries for my CM-15?

A: The CR123 batteries are standard camera batteries that can be purchased at your local Wal-Mart, Radio Shack, local drug store or any other place that sells batteries.

Q: What is the actual size of the CM-15?

A: 3 (Length) x 2.43 (Width) x 1.37 (Height) inches.

Q: How much does the CM-15 weigh?

A: This laser weighs 5.4 oz